



**NORTHERN MICHIGAN
UNIVERSITY**

EAN Setup Guide

Global Telecom Indoor/Outdoor Unit



SUPPORT: 1(888)458-8668 OR EANSUPPORT@NMU.EDU


Table of Contents

Box Contents	2
Getting Started	3
Hardware Overview	3
Indoor Setup	4
Outdoor Setup	5-6
Mounting the Outdoor Unit	7
Antenna Tuning and Signal	8
Checking Signal Strength	8
LTE Information Page	9-10
EAN Contact Information	11

Box Contents

In The Box

- 1 x Global Telecom Indoor/Outdoor antenna
- 1 x Power adapter
- 1 x Power line cable
- 1 x Ethernet cable
- 1 x Mounting kit (mounting brackets, bolts, U-bolts, nuts)




Important Information

Your Global Telecom Antenna is not a wireless router. You may connect one computer to the internet using an Ethernet cable from the antenna to the computer following the instructions in this guide. If you want wireless internet, you will need to connect a wireless router to the Global Telecom Antenna following the instructions in this guide.

Questions or concerns? Contact EAN support at 888-458-8668 or email eansupport@nmu.edu.

Getting Started

Hardware Overview



Indoor Setup

Use this setup if you will be placing the Global Telecom antenna inside of your home.. Please point your unit out through a solid surface and not through a window or glass.

Step 1: Unpack the unit and all of the components from the box. Verify that you have all components. Refer to page 2 for full list.

Step 2: Locate the best position for the Global Telecom Antenna inside of your home. You've been provided with a signal area map that shows you the proximity of the tower from your home. Please face the unit in the direction of the tower for the best-possible service.

Step 3: Plug the Ethernet cable into the bottom of the Global Telecom antenna.

Step 4: Connect the Ethernet cable connected to the antenna to the POE port on the power adapter. Make sure to use the correct port. **Connecting the POE port to anything other than the Global Telecom antenna can result in damage to the device.** (see Figure 1).




Figure 1 – POE power adapter with Ethernet cables

Step 5: Plug a different Ethernet cable into the Internet or WAN port on your home router or the Ethernet port on your computer, and then plug the other end of the Ethernet cable into the LAN port on the POE power adapter.

Step 6: Plug the POE power adapter into an electrical outlet using the power cable provided.

Step 7: If necessary, follow the instructions in your router's manual to connect to the router and finish setting up your connection. If you do not have a router, we recommend the Linksys AC1750 (available online or at your local technology store).

Outdoor Setup

Use this setup if you will be placing the Global Telecom antenna outside. Please ensure you read and understand these instructions before mounting your antenna outside. The elevation recommendation given to you is a minimum requirement in order to have access to the EAN internet service.

Step 1: Unpack the unit and all of the components from the box. Verify that you have all components. Refer to page 2 for full list.

Step 2: Locate the best position for the antenna on the outside of your home. You've been provided with a signal area map that shows you the proximity of the tower from your home. Please face the antenna toward the tower for the best-possible service. If you are unable to get service please call the technical support line at (888) 458-8668

Step 3: Mount the antenna to the outside of your home. For more detailed directions, see the section titled “**Mounting the Outdoor Antenna**” contained in this guide.

Step 4: Slide the weather shield over the Ethernet cable, then slide the rubber gasket over the Ethernet cable.

Step 5: Plug the cable into the unit then slide the rubber gasket into the threaded cable guide (see *Figure 2*).




Figure 2 – Ethernet cable connected to Global Telecom antenna with rubber gasket and weather shield.

Step 6: Screw the weather shield onto the threaded cable guide to secure the Ethernet cable and protect it from the weather.

Step 7: Run the outdoor Ethernet cable from the Global Telecom Antenna into your house.

Step 8: Connect the outdoor Ethernet cable to the POE port on the power adapter. Make sure to use the correct port (*see Figure 3*). **Connecting the POE port to anything other than the Global Telecom antenna can result in damage to the device.**




Figure 3 – POE power adapter with Ethernet cables

Step 9: Plug a different Ethernet cable into the Internet or WAN port on your home router or the Ethernet port on your computer, and then plug the other end of the Ethernet cable into the LAN port on the POE power adapter.

Step 10: Plug the POE power adapter into an electrical outlet using the power cable provided.

Step 11: If necessary, follow the instructions in your router's manual to connect to the router and finish setting up your connection. If you do not have a router, we recommend the Linksys AC1750 (available online or locally at your local technology store).

Mounting the Outdoor Antenna

To connect the pole mount assembly, perform the following steps:

Step 1: Attach the mounting bracket to the back of the Global Telecom antenna and screw into place. (see *Figure 4*)





Figure 4



Figure 5

Step 2: Take the mounting bracket and place it against your mounting post. Secure the bracket using the two U shaped bolts from the mounting kit and screw them into place as shown (see *Figure 5*)

Step 3: Secure the Global Telecom antenna to the mounting bracket attached to your mounting post using the remaining bolts from the mounting kit. A visual guide has been included below.



Antenna Tuning and Signal

Checking Signal Strength

The quickest way to check signal strength is to look on the back of the unit. The Global Telecom antenna will show you what the current signal strength is with indicator lights under the RF section (see *Figure 6*):



Figure 6: Antenna lights on the back of the device.

If you are unable to see the back of the Global Telecom antenna, you can log into it using the web interface. To access the web interface, you will need to do the following:


1. Wait for the unit to fully power on. (3-5 minutes)
2. Make sure you are connected to the Global Telecom Antenna (either via Ethernet or through a wireless router)
3. Open a web browser on your device connected to the antenna.
4. Enter **http://10.1.1.1** in the address bar.
5. Enter **Global_system** when prompted for the password
6. Click **Login**


Once you are logged in, you are presented with a screen titled **LTE Information**. This screen contains all the detailed information about your LTE device. See “**LTE Information Page**” in this guide for more information.

LTE Information Page

Below is an example of the information page. Please note the RSRP, RSRQ, and SINR sections (*red arrows*). You are going to use these values to determine the best position for the Global Telecom antenna. These sections are described in detail on page 10 of this guide.

Firmware: GLC130D V2.2.1 PACK 9 (Ver.851)





Exit
admin

LTE
Network
Security
Management
Maintenance
Status

Overview
ND&S
PLMN Selection
eNB Settings
Bearer Settings
SIM Card
PIN Management
Command Shell

LTE Information
Help

System Information

Manufacturer	Global
Model Name	GLC130D
Chip Model	ALT38XX
Serial Number	K4100D133FA0
IMEI	862344030088966
IMSI	312590100004697
Duplexing Scheme	FDD
Supported Band	7/41
Firmware Version	HN_02_02_01_00_54

System Information:

This section shows the basic device 4G Radio hardware and firmware information.

Connection:

This section shows the status of connection for 4G Radio.

Radio Information

RSRP	←	-100 / -102 dBm
RSSI		-85 dBm
RSRQ	←	-10 dB
SINR	←	14 dB
CQI		10
Transmit Mode		Open loop MIMO
UL/DL Bandwidth		20000 / 20000 KHz
UL/DL Earfcn		3350 / 3350
RRC State		active
EMM State		registered home
PCI		69
eNodeB ID		11
Cell ID		9
TX Power		12.4 dBm
UL/DL Throughput		0 / 0 Kbps

Connection

RSRP:

The RSRP is the measurement of your received signal strength. Your service speeds will be impacted if your RSRP value is in the fair or poor category. For example, -128 dBm means your signal is poor and not usable. Use the chart below for RSRP value reference.

RSRP	Signal Strength
> -90 dBm	Excellent
-90 dBm to -105 dBm	Good
-106 dBm to -120 dBm	Fair
< -120 dBm	Poor

RSRQ:

The RSRQ is a measurement that represents the quality of the received signal. You want to be sure your signal levels are measured at excellent or good quality or your speeds will be impacted. For Example, if your RSRQ value is -15 dB your service is unusable. Use the chart below for RSRQ value reference.

RSRQ	Signal Quality
> -9 dB	Excellent
-9 dB to -12 dB	Good
< -13 dB	Fair to Poor

SINR:

The SINR is a value used to measure the quality of the connection between the antenna and the EAN cell tower. It represents any interference in the LTE connection. You want to keep this number above 6. Use the chart below for SINR value reference.

SINR Value	Throughput
> 10	Excellent
6 to 10	Good
0 to 5	Fair
< 0	Poor

EAN Support Contact Information

Phone

Local: (906)227-2957
Toll Free: 1(888)458-8668

Email

eansupport@nmu.edu

Location & Hours of Operation

1401 Presque Isle Ave
NMU Cohodas Building
Room 504
Marquette, MI 49855

Open:
Monday – Friday
8:00AM – 5:00PM EST

Closed on holidays*

*Closed whenever Northern Michigan University is closed.