EAN Contact Information

Location

1401 Presque Isle Ave NMU Cohodas Building Room 501 Marquette, MI 49855

Hours of Operation

During School Year Monday – Friday 8:00AM – 5:00PM During Summer Break Monday – Friday 7:30AM – 4:00PM Closed while Northern Michigan University is closed.

Phone Support

888-458-8668 906-227-2957

Online Support

eansupport@nmu.edu eansupport.nmu.edu

Need In-Home Support?

Here are some people who can help!

Greater Marquette Area: Cybernetics Lab – (906)250-7507 | consult@cyberneticslab.com

Houghton Area: Duane Bucheger – (906)399-3141

Entire Upper Peninsula: Donn Wolf – (906)227-1268

**Individuals listed above are not affiliated with the Educational Access Network and we cannot guarantee their workmanship or quality of service.

Property of Northern Michigan University Version 3: April 2021



Quick Setup Guide



BAICELLS ANTENNA Support: 1(888)458-8668 or eansupport.nmu.edu

Table of Contents

Box Contents	1
Indoor Setup	2
Outdoor Setup	3
Checking Your Signal Strength	4
Troubleshooting	5
I cannot connect to the internet	5
My internet is very slow	5
I cannot see my WiFi at my home	5

Troubleshooting

I cannot connect to the internet.

Step 1: Ensure your unit is powered on.

Step 2: Check to be sure you have at least 3 lights of RF signal on the side of your device. If you do, check your signal levels by following the steps on page 4.

Step 3: Unplug the Ethernet cable from the POE port of the power adapter, wait for 10 seconds, then plug it back in. Wait up to *15 minutes* for the device to come back online.

Step 4: Plug your computer directly into the LAN port of the POE power adapter and make sure your router is powered off. If the internet works, you may have a problem with your router.

My Internet is slow.

Step 1: Follow the steps on page 4. If your signal is below the Good range, you will have slower speeds.

Step 2: If all of your signal levels are in the good range, check to see how many devices are streaming in your home. The more devices you use, the slower your internet will be.

Step 3: Contact us to see if a speed upgrade is right for you.

I cannot see my WiFi at my home.

The Baicells antenna does not produce a wireless signal. Please check your wireless router for issues and contact the router manufacturer with any questions.

Checking Your Signal Strength

Step 1: Wait for your antenna to fully power on

Step 2: Connect a computer directly to the LAN port of your POE Power adapter. *These steps may not work if you are connected through WiFi.*

Step 3: Open a web browser (Chrome or Firefox) on your device and navigate to **http://192.168.150.1** using your address bar.

Step 4: When prompted for a password, enter **admin** for the user and **admin123** for the password

Step 5: Once you are logged in, you should automatically be shown the **Overview** page. Under **LTE Status** you will see dB values for *RSRP*, *RSRQ*, and *SINR*. **Compare RSRP**, **RSRQ**, and *SINR* values to the table **below.** If your signal levels are within the Good range, you should be getting close to your advertised speed.

IMPORTANT NOTE: If you are unable to get your antenna in our recommended range of signal, expect to see slow, intermittent connections until you are able to increase signal levels.

	RSRP	RSRQ	SINR
Recommended	> -90dBm	> -8dB	> 10
Good	-90dBm to -105dBm	-8dB to -10dB	8 to 10
Fair	-105dBm to -110dBm	-10dB to -12dB	6 to 8
Poor	< -110dBm	< -12dB	< 6

Box Contents

In The Box

1 x Baicells EG7035E-M1 Outdoor Antenna 1 x Power-Over-Ethernet Power Adapter 1 x Power Line Cable 1 x Mounting Kit 1 x CAT 5e Ethernet Cable

Other Important Information

This is a quick setup guide to outline a basic setup for your device. For a detailed look in the setup, please visit our website at <u>eansupport.nmu.edu</u> and click on *Getting Started*.


Your Baicells Antenna is not a wireless router. You may connect one computer to the internet using an Ethernet cable from the LAN port of the power adapter to the computer following the instructions in this guide. You may also connect a wireless router (sold separately) to have WiFi in the home.

Any issues contact EAN support at 888-458-8668, email eansupport@nmu.edu, or visit our website at eansupport.nmu.edu.


Indoor Setup

Use this setup if you will be placing the Baicells antenna inside of the home. Please point the unit out through a solid surface and avoid windows. If you have a metal roof or siding, you will need to mount this device outside.

Step 1: Plug the Ethernet Cable into the side of the antenna (behind the door)



Step 2: Plug the Ethernet Cable from the antenna into the POE port of your power adapter. Plug another cable from the LAN port into a computer or WiFi Router.



Step 3: Plug the Power Adapter into the wall and point the front end of your antenna towards your nearest tower. It may take up to *15 minutes* for it to find your nearest tower.


Outdoor Setup

Use this setup if you will be placing the Baicells antenna outside of your home. Please read all instructions before mounting outside. You may need a longer Ethernet cable in order to setup your equipment outside.

Step 1: Plug the Ethernet Cable into the side of the antenna (behind the door)until you hear a click, ensuring the cable is securly in place. Feed the cable through the designated opening and tighten the two screws to waterproof the connection.



Step 3: Attach the base mounting bracket to the back of the Baicells antenna (indicated blue). Feed the U-Bolt through the adjustable bracket and fit it around your mounting pole. Finally, attached the toothed bracket on the opposite end of the pole, tightening the bracket using the included bolt nuts (indicated yellow)



Step 4: Run the Ethernet cable into your home, and follow steps 2 & 3 on page 2 **Indoor Setup** to finish your setup.